

It's recommended to use a soft cloth or gloves when handling the fixture.

#### Wiring Instructions

1. Attach universal crossbar to J-box, aligning holes to desired location in regard to backplate ball screws.
2. Connect positive supply wire (typically black or the smooth, unmarked side of the two-conductor cord) to positive fixture lead with appropriately sized twist on connector.
3. Connect negative supply wire (typically white or the ribbed, marked side of the two-conductor cord) to negative fixture lead.
4. Please refer to the grounding instructions to complete all electrical connections.
5. Tuck the connected wires into the J-box. Align screw holes from fire plate to the universal crossbar. Thread the screws through, tightening the fire plate flush to the wall.
6. Slide shade over fire plate by angling up and locking into top latch. Secure using set screw at bottom.

#### Grounding Instructions

For positive grounding in a 3-wire electrical system, fasten the fixture ground wire (typically copper or green plastic coated) to the fixture mounting crossbar with the ground screw.

Note: On straps for screw support fixtures, first install the two mounting screws in strap. Any remaining tapped hole may be used for the ground screw.

#### Light bulb Replacement

1. Remove set screw from bottom of the fixture.
2. Remove shade body by simultaneously angling bottom away from the wall and gently lifting it upwards, releasing it from top latch.
3. Remove diffuser from mounting plate to expose bulb.
4. Replace bulb and restore fixture by putting parts back in place.

