

It's recommended to use a soft cloth or gloves when handling the fixture.

Wiring Instructions

1. Attach universal crossbar to J-box.
2. Connect positive supply wire (typically black or the smooth, unmarked side of the two-conductor cord) to positive fixture lead with appropriately sized twist on connector.
3. Connect negative supply wire (typically white or the ribbed, marked side of the two-conductor cord) to negative fixture lead.
4. Please refer to the grounding instructions to complete all electrical connections.
5. Tuck the connected wires into the J-box. Align screw holes from back plate to the universal crossbar. Thread the screws through, tightening the back plate flush to the ceiling/wall.
6. Align latch on glass shade with latch on back plate. Turn shade clockwise until shade is secured.

Grounding Instructions

For positive grounding in a 3-wire electrical system, fasten the fixture ground wire (typically copper or green plastic coated) to the fixture mounting crossbar with the ground screw.

Note: On straps for screw support fixtures, first install the two mounting screws in strap. Any remaining tapped hole may be used for the ground screw.

Light Bulb Replacement

1. Turn glass shade counter clockwise to release from back plate.
2. Gently pull bulb from socket and replace.
3. Align hardware on glass shade with hardware on back plate. Turn shade clockwise until shade is secured.

