

It's recommended to use a soft cloth or gloves when handling the fixture.

#### Wiring Instructions

1. Measure desired drop height of fixture. Mark necessary lengths on (4) steel wires.
2. Feed steel wires through grips on canopy at marked lengths. Twist grippers to tighten and secure wire in place.
3. Attach universal crossbar to J-box, aligning holes in regard to fire plate holes and desired fixture direction.
4. Align center holes of fire plate to the holes in the universal crossbar. Using remaining holes on fire plate as a guide mark locations for dry wall anchors.
5. Install dry wall anchors. Using provided dry wall screws install fire plate flush to ceiling. Secure fire plate to universal crossbar using provided screws.
4. Connect positive supply wire (typically black or the smooth, unmarked side of the two-conductor cord) to positive fixture lead with appropriately sized twist on connector.
5. Connect negative supply wire (typically white or the ribbed, marked side of the two-conductor cord) to negative fixture lead.
6. Please refer to the grounding instructions to complete all electrical connections. Tuck the connected wires into the J-box.
8. Raise the fixture by the canopy, and secure over fire plate using provided side screws.
9. To level/adjust fixture loosen one gripper at a time and feed or pull steel wire. Twist gripper to secure wire in place. Repeat as necessary.

#### Grounding Instructions

For positive grounding in a 3-wire electrical system, fasten the fixture ground wire (typically copper or green plastic coated) to the fixture mounting crossbar with the ground screw.

Note: On straps for screw support fixtures, first install the two mounting screws in strap. Any remaining tapped hole may be used for the ground screw.

#### Light bulb Replacement

